# Temperature and Humidity Transducer with Bacnet & Modbus port

#### **Description**

Duct temperature and humidity sensor / transmitter is applicable to all kinds of building automation, environment monitoring, HVAC systems. Product appearance is simple, direct connection terminals, convenient installation.Products use high performance embedded microprocessor, and high-precision sensors to meet all kinds of high precision, high stability of the temperature and humidity measurement requirements, and variety needs of different environments. Duct temperature sensor / transmitter has current, voltage, 485 output signal to select, using 485 serial port out put and Modbus communication protocol. It is commonly used in HVAC, electrical plant, environment monitoring, dynamic environment monitoring, agricultural environmental monitoring, meteorological environmental monitoring, environmental monitoring of biological pharmacy, airport, subway stations, hotel, museum,

#### **Higslights**

- -High precision temperature and humidity sensor
- -Applicable to all types of air environmental monitoring
- HVAC systems
- -Advanced circuit design, high accuracy, stable performance
- -Appearance is concise, easy to install, cost-effective


#### **Specifications**

| Typical Applica-       | Duct mount indoors                                      |                      |
|------------------------|---|----------------------|
| Output Signal<br>Type  | 4-20mA,0-10V  |                      |
| Output Signal<br>Drive | >500Ω for mA mode,75mA max output drive for voltagemode |                      |
| Power                  | 15-24V+/-10%, AC or DC,1watt typical                    |                      |
| Operating Temp         | -30~+60°C,0-95%non condensing                           |                      |
| Plastic Housing        | Flammability rating UL94V0 file E194560                 |                      |
| Control Features       | N/A   |                      |
|                        | Sensor Type   | Capacitive           |
| HUM                    | Range   | 0-100%Non-Condensing |
| 110111                 | Accuracy  | 5%@25°C,20~80%       |
|                        | Drift   | <0.5%RH/year         |
|                        | Sensor Type   | 10K thermistor       |
| TEMP                   | Range   | -40~150°C(-60~340°F) |
|                        | Accuracy  | <±0.5°C@25°C         |
| Size                   | 72.2mmX64mmX38.4mm                                      |                      |






# Dimension




# Wiring Diagram



# **Modbus Register List**

| ADDRESS | Register Description  |  |
|---------|---|--|
| 0-3     | Serial number   |  |
| 4       | Software version  |  |
| 6       | Modbus Address  |  |
| 8       | Hardware version  |  |
| 17      | Switch 5, 1=010V, 0=420mA   |  |
| 18      | Switch 1-2, 0=0-100,1=-2080,2=050,3=-5050                               |  |
| 19      | Switch 3-4, 0=dewPoint, 1=enthalpy, 2=absolute humidity,3=real humidity |  |
| 25      | potentiometer R1 AD value   |  |
| 27      | potentiometer R2 AD value   |  |
| 34      | SHT 35 Temperature  |  |
| 35      | SHT 35 Humidity   |  |
| 45      | NTC temperature   |  |
| 36      | potentiometer R1 offset value   |  |
| 37      | potentiometer R2 offset value   |  |
| 38      | Temperature with offset   |  |
| 39      | Humidity with offset  |  |
| 41      | Dew point value   |  |
| 42      | Enthalpy value  |  |
| 44      | bsolute humidity  |  |
| 51      | est switch, if on, input voltage to register 52,53                      |  |
| 52      | Input voltage for Temperature output, 500 mean 5.00 v                   |  |
| 53      | input voltage for humidity output, 500 mean 5.00 v                      |  |
| 54      | input current for temperature output, 4 mean 4mA                        |  |
| 55      | input current for humidity output, 4 mean 4mA                           |  |
| 60-76   | NTC sensor 17 calibration points  |  |
| 80      | NTC sensor's AD value   |  |

# **Part Number Scheme**



# **Mounting Installation**


1)slotted screwdriver




Captiver screw(slotted screw)




2)Unfasten screw at cover,turn the captive screw ½ turn till it pops out





3)Open the cover



4)There are three small holes as red arrows showed below inside the box for fastening self tapping screws









5)Re-fasten screw at cover



#### **Accuracy Curves**





# **Bachnet Object List**

| Supported BACnet Object Types   |
|---|
| analog-value, device  |
| Supported BACnet Services   |
| who-is, i-am  |
| object-identifier, object-name, object-type, present-value, units, object-list, vendor-id, vendor-name, system-status, confirmed-service, unconfirmed-service |

| MSTP Object  |                               |   |
|--------------|-------------------------------|---|
|              | AV0:baudrate select           |   |
| Analog-value | AV1:Temperature range         | 0=0-100°C; 1=-2080°C ;2=050°C; 3=-5050°C                    |
|              | AV2:Humidity range            | 0=dewPoint, 1=enthalpy, 2=absolute humidity,3=real humidity |
|              | AV3:Protocol                  | 0: Modbus; 1:Bacnet   |
|              | AV4:Output type               | 0: 4~20mA; 1: 0-10V   |
|              | AV5:Temperature               |   |
|              | AV6:Reality Humidity          |   |
|              | AV7:Absolute Humidity         |   |
|              | AV8:Dew Point                 |   |
|              | AV9:Enthalpy                  |   |
|              | AV10:Temperature Offset       | Range: -4.0 ~ 4.0   |
|              | AV11: Humidity Offset         | Range: -4.0 ~ 4.0   |
| Device       | device-identifier,device-name |   |

